


SR1315




Scan for video instructions.

To register your warranty, visit
seriouslights.com/warranty

For advice. For help. For repair:


+44 1296 390 390
seriouslights.com

15 Faraday Road | Aylesbury | Bucks,
HP19 8RY | Great Britain



High Definition Light Pro

Instructions




Keep for reference



Getting Started


What's in the box?

① Lamp Body + ① Lamp Base + ① Charger Plug




Assembly

- ① Fit lamp body to base.
- ② Screw nut clockwise to lock.



Operation Summary



Switch

Press to turn on/off.
Hold for 3s to turn off standby light.

Dimmer

Indicator lights show brightness level.



Beam Control

Twist to adjust spread.


Snooze

Turn light on and hold switch 4s.
Indicators flash briefly.
Light will turn itself off in 30 min.

Beam Width




Light Engine Replacement



Remove/Refit

Switch lamp off to cool.
Pull side tabs to remove.
To refit align tabs and push.


Light Positioning



Optional Battery *(sold separately)*

Powers light for up to 6.5 hours.

- 1 Unclip battery cover on base.
- 2 Swap spacer for battery pack.
- 3 Replace cover.



Light will not operate without spacer or battery.

When plugged in with battery fitted, the battery will charge but the light will use mains power.


Q: How do I know how much battery charge is left?

A: Press switch twice. Indicator lights will show the remaining charge.

Q: How many times can the battery be recharged?

A: At least 500 cycles.

Optional Remote Control *(sold separately)*



Q: How does the favourite setting work?

A: Set desired brightness and hold down favourite button for 5s.

Q: How long does the remote battery charge last?

A: Approx. six months depending on use.