

SR1322




Scan for video instructions.

To register your warranty, visit  
[seriousreaders.com/warranty](https://seriousreaders.com/warranty)

For advice. For help. For repair:


**+44 1296 390 390**  
**seriousreaders.com**

15 Faraday Road | Aylesbury | Bucks,  
HP19 8RY | Great Britain



# High Definition Light Mini

## Instructions



Keep for reference




# High Definition Light Mini

## Getting Started


Your light arrives partially charged. To charge it, connect the supplied charger to the USB-C port on the base and plug it into a wall socket.

The indicator light will flash while charging and become solid when full. You can use the light while it is charging.



## Dimmer

A quick click turns the light on and off. To adjust brightness, press and hold the switch. The brightness will cycle. Release the switch to set your desired level. The light will remember your setting unless battery is removed. Green power indicator on switch turns on/off, and dims with the light.



# High Definition Light Mini

## To Change The Bulb

Unscrew the shade. Pull the bulb out to remove it. **Do not twist the bulb.** Fit the new bulb and reattach the shade.

## Battery Life

A full 4-hour charge provides up to 4.5 hours of use at full power, or over 20 hours when dimmed. The indicator light will flash to warn you when the battery falls below 20%. The standard USB port on the base can be used to charge your phone or tablet.

## Battery Replacement

The battery is designed for at least 500 charge cycles. To replace it, unclip the cover on the base, remove the old battery, and insert the new one, ensuring the metal contacts line up correctly.


## Battery Disposal

Rechargeable batteries are hazardous waste and should not be thrown in the rubbish. Please take them to a local recycling centre or return them to us for proper disposal. Serious® is WEEE registered and provides a disposal service at Unit 15-16 Faraday Road, Aylesbury, HP19 8RY.

## Safety Reminder

Please note the following safety advice:

- For indoor use only.
- Keep out of the reach of children.
- Do not disassemble.
- Avoid using in extreme temperatures.
- Use only original or certified cables.



## Replacement Parts

For replacement bulbs and batteries visit:

[seriousreaders.com/info/hdmini](https://seriousreaders.com/info/hdmini)

Or contact us on **+44 (0) 1296 390 390**